

SureCross™ MultiHop Quick Start Guide

A set-up guide for the SureCross MultiHop wireless systems



Read these instructions before using your SureCross MultiHop radios. Do not discard these instructions.

For more detailed information about installing and using your SureCross products, download and read the SureCross Wireless I/O Network Manual, p/n 151317.

Important: Never Operate 1 Watt Radios Without Antennas.

To avoid damaging the radio circuitry, never power up SureCross Performance or SureCross MultiHop (1 Watt) radios without an antenna.

WARNING . . . Not To Be Used for Personnel Protection

Never use these products as sensing devices for personnel protection. Doing so could lead to serious injury or death. These devices do NOT include the self-checking redundant circuitry necessary to allow their use in personnel safety applications. A device failure or malfunction can cause either an energized or de-energized output condition. Consult your current Banner Safety Products catalog for safety products that meet OSHA, ANSI, and IEC standards for personnel protection.




p/n 152653 rev. B

Step 1: Select the Master, Repeater, and Slave Radios

Before beginning operation, you must select one radio to be the master radio. Set the other MultiHop radios to operate as either repeaters (default setting) or slaves.

- Remove the top covers of the MultiHop radios.
- Set one unit to be the master radio.
- Set the other MultiHop radios to be repeaters or slaves.
- Set additional DIP switches now. (See the DIP Switches section of the devices' datasheets for the positions and descriptions.)



Default configuration	DIP Switches					
	1	2	3	4	5	6
Serial baud rate: 19.2k	OFF	OFF				
No parity			OFF	OFF		
1 Watt transmit mode (900 MHz only)					OFF	
Modbus application mode						OFF

	DIP Switches	
	7	8
Repeater	OFF	OFF
Master	OFF	ON
Slave	ON	OFF

Step 2: Apply Power

The FlexPower Multihop radios will operate when powered from the brown or gray wire. It is not necessary to supply power to both.

- Apply power to the radios by connecting the cable as shown in the wiring diagram.

5-pin Euro-style connector	"C" model terminals	Pigtail wire color	10-30V dc powered radios*	Solar or battery-powered radios**
1	V+	Brown	+10-30V dc	
3	V-	Blue	dc common (GND)	dc common (GND)
5	B+	Gray		3.6-5.5V dc

* Only use pin 5 (gray wire) for radios capable of being powered by solar or battery modules.
 ** For solar and battery-powered radios, do not apply more than 5.5V dc to pin 5 or the B+ terminal.

For the communication pin configuration or more details, refer to your specific devices' datasheets.



Step 3: Bind the Radios to Form Networks


Binding MultiHop radios to the master radio ensures the MultiHop radios only exchange data within their wireless network. MultiHop radios will not communicate until they are bound. Bind the radios before installing them to their final locations.

On the Master radio

- Triple click button 2 to enter binding mode. For models with only one button, triple click the button.
For the two LED/button models, both LEDs flash red. For single LED/button models, the LED flashes alternatively red and green.

On the Repeater or Slave radios

- Triple click button 2 on the slave/repeater radio. For models with only one button, triple click the button.
The child radio enters binding mode and searches for any Master radio in binding mode. While searching for the Master radio, the two red LEDs flash alternately. After the child radio finds the Master radio and is bound, both red LEDs are solid for four seconds, then both red LEDs flash simultaneously four times.
- Use both rotary dials to assign a decimal MultiHop Radio ID between 11 and 61. The left rotary dial represents the tens digit (1-6) and the right dial represents the ones digit (0-9) of the MultiHop Radio ID.
- Repeat steps 2 and 3 for as many slave or repeater radios as are needed for your network.



On the Master radio

- After all MultiHop radios are bound, exit binding mode on the master by double-clicking button 2. All radio devices begin forming the network after the master data radio exits binding mode.

Step 4: Verify Communications

When testing the devices before installation, verify the radio devices are at least two meters apart or the communications may fail.

LED 1	LED 2	Status
Green ON, then Green flashing		Slave/repeater: entering RUN mode
Green flashing		Master: in RUN mode Slave/repeater: synchronized to the parent radio
Red solid		Slave/repeater: detected parent radio and searching for other parents within range
Red flashing		Slave/repeater: searching for a parent radio
	Yellow solid	Slave/repeater: selects a suitable parent Master: power applied
	Yellow flashing	Slave/repeater: serial data packets transmitting between radio and its parent Master: serial data packets transmitting between master and its children
	Red solid	Slave/repeater: synchronizing to selected parent radio
	Red flashing	

Step 5: Conduct a Site Survey Using the Menu System

Perform the site survey before installing your network to pre-screen a site for its radio communication potential, compare link quality in different locations, or assist with final antenna placement and aiming.

Site surveys can be conducted from the master, repeater, or slave radios. For a more detailed description of the parent-child relationships, refer to the device data sheets.

Step 1. On a data radio device, press button 1 until the display reads *SITE.

Step 2. Single-click button 2 to enter the Site Survey menu.

Step 3. **From the master radio:** Single-click button 2 to display the child radio's device address. (A radio's device address is displayed under its *RUN menu). Single click button 1 to scroll between all the master radio's children. When you reach the child radio you want to run the Site Survey with, single-click button 2.

From the repeater radio: Single-click button 1 to cycle between PARENT and CHLDRN. Single-click button 2 to select PARENT or CHLDRN. If conducting the Site Survey with one of the repeater's children, single-click button 1 to scroll among a repeater's children radios. (Each data radio's device address is displayed under its *RUN menu.) Single-click button 2 at the device address screen to select the child or parent and begin the Site Survey.

From the slave radio: Single-click button 2 to display PARENT. Single-click button 2 to begin the Site Survey.

Step 4. The site survey begins. LED 2 on both the parent and child radios flash for every received RF packet. To indicate the parent is in site survey mode, LED 1 is a solid green. The radio analyzes the quality of the signal between the parent and child by counting the number of data packets received and measuring the signal strength (green, yellow, and red).

Step 5. Examine reception readings (G, Y, R, M) of the devices at various locations. M displays the percent of missed packets while G, Y, and R display the percent of received packets at those signal strengths.

GRN = GREEN excellent signal strength; YEL = YELLOW good signal strength; RED = RED marginal signal strength; MIS = Percentage of missed packets.

Step 6. During a site survey, single-click button 2 to pause/resume autoscrolling the results. While paused, button 1 advances through the four signal strength categories. Double-click button 2 to exit the results display.

Step 7. Double-click button 2 on either the child or the parent device to exit site survey. The devices automatically resume operation.

Step 6: Installing Your SureCross Radios

For most outdoor applications, we recommend installing your SureCross devices inside a secondary enclosure. If not using an enclosure, mount the radios where rain or snow will drain away from the unit.

To minimize the damaging effects of ultra-violet radiation, avoid mounting the radios facing intense direct sunlight.



MultiHop Configuration Tool (MHCT)

Banner's MultiHop Configuration Tool offers an easy way to configure and view your MultiHop radio network.

The MultiHop Configuration Tool requires the USB to RS-485 converter cable, BWA-UCT- 900.




Device	Device Ty...	MultiHop Radio...	Device Address	Signal Stren...	Green	Yellow	Red	Miss...	Model Num...
MultiHop Master	Master	12	58081	---	---	---	---	---	152064
MultiHop Data Radio	Slave	30	26026	98 %	98	0	0	2	151687
MultiHop Radio IO H1	Repeater	13	55143	80 %	62	18	0	20	151685
DATA RADIO DEVICE	Repeater	11	51584	49 %	4	41	4	51	148375
MultiHop Data Radio	Slave	33	26035	98 %	98	0	0	2	151687
MultiHop Data Radio	Slave	34	26029	100 %	100	0	0	0	151687
MultiHop Data Radio	Slave	31	26027	100 %	91	9	0	0	151687
MultiHop Data Radio	Slave	35	26032	100 %	100	0	0	0	151687
MultiHop Data Radio	Slave	38	26028	100 %	100	0	0	0	151687
MultiHop Data Radio	Slave	37	26034	100 %	100	0	0	0	151687
MultiHop Data Radio	Slave	36	26031	98 %	98	0	0	2	151687
MultiHop Data Radio	Slave	32	26030	98 %	98	0	0	2	151687
MultiHop Data Radio	Slave	39	26033	95 %	96	0	0	4	151687

MultiHop Radio Mounting Template

The gray-shaded section represents the DX80...C housings' removable terminal headers.

Only if you are using the printed copy provided by Banner can this be used as a mounting template.



For additional information, including installation and setup, weatherproofing, device menu maps, troubleshooting, and a list of accessories, please refer to the SureCross™ MultiHop product manual, Banner p/n 151317.



Banner Engineering Corp. warrants its products to be free from defects in material and workmanship for one year following the date of shipment. Banner Engineering Corp. will repair or replace, free of charge, any product of its manufacture which, at the time it is returned to the factory, is found to have been defective during the warranty period. This warranty does not cover damage or liability for misuse, abuse, or the improper application of the Banner product.

THIS LIMITED WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES WHETHER EXPRESS OR IMPLIED (INCLUDING, WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE), AND WHETHER ARISING UNDER COURSE OF PERFORMANCE, COURSE OF DEALING OR TRADE USAGE.

This Warranty is exclusive and limited to repair or, at the discretion of Banner Engineering Corp., replacement. **IN NO EVENT SHALL BANNER ENGINEERING CORP. BE LIABLE TO BUYER OR ANY OTHER PERSON OR ENTITY FOR ANY EXTRA COSTS, EXPENSES, LOSSES, LOSS OF PROFITS, OR ANY INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES RESULTING FROM ANY PRODUCT DEFECT OR FROM THE USE OR INABILITY TO USE THE PRODUCT, WHETHER ARISING IN CONTRACT OR WARRANTY, STATUTE, TORT, STRICT LIABILITY, NEGLIGENCE, OR OTHERWISE.**

Banner Engineering Corp. reserves the right to change, modify or improve the design of the product without assuming any obligations or liabilities relating to any product previously manufactured by Banner Engineering Corp.

The manufacturer does not take responsibility for the violation of any warning listed in this document.

CAUTION. Make no modifications to this product. Any modifications to this product not expressly approved by Banner Engineering could void the user's authority to operate the product. Contact the Factory for more information.

Lightning Arrestors/Surge Protection. Always use lightning arrestors/surge protection with all remote antenna systems to avoid invalidating the Banner Engineering Corp. warranty. No surge protector can absorb all lightning strikes. Do not touch the SureCross device or any equipment connected to the SureCross device during a thunderstorm.

All specifications published in this document are subject to change. Banner reserves the right to modify the specifications of products, prior to their order, without notice. Banner Engineering reserves the right to update or change documentation at any time. For the most recent version of any documentation, please refer to our website: www.bannerengineering.com. © 2009-2011 Banner Engineering Corp. All rights reserved.